

Thank you for purchasing our BRAKE CALIPER decals.

Following these simple instructions will help you install your decals with ease. If you're giving a facelift to your calipers by painting them, please allow the paint to dry thoroughly before applying decals. We G2 Epoxy Paint.

1. Always make sure the minimum application temperature is above 46°F.
2. Preparation of the caliper is very important. We recommend using a brake cleaner to free the caliper of all brake dust, dirt, grime, etc. Not only is it a great cleaner, it dries very fast so you don't have to wait around to apply the decals.
3. Determine which size decal you will be placing on your caliper and where you will be sticking it. Place the decal face down and slowly peel the paper backing off.
4. Position the decal over your brake caliper or brake drum and gently press in the middle of the decal once you find the proper position.
5. From the middle of the decal, press and slide your finger over the decal towards the ends. Repeat this several times over the whole decal to make sure it conforms to your caliper.
6. SLOWLY peel the application tape off at 180 degrees. Keep an eye out to make sure the lettering doesn't lift off the surface. If the lettering happens to lift up while doing so, place the application tape over the letters and rub with firm pressure to ensure the letters stick to the calipers.